



NOTES:
 1. Use thread locking compound.
 2. Install resilient SAFETY SURFACE.